# **RV Terminal**Centration System



User manual



Knowledge of this manual is required for the operation of the instrument. Please therefore make yourself familiar with the contents of this manual and pay special attention to information concerning the safe operation of the instrument.

The specifications are subject to change; the operating manual is not covered by an update service.

- © Unless expressly authorized, forwarding and duplication of this document, and the utilization and communication of its contents, are not permitted. Violations will entail an obligation to pay compensation.
  - All rights reserved in the event of the granting of patents or registration of a utility model.

Pa	ige
Copyright	1
Instrument Safety	3
Warning labels and notes	
Notes on instrument safety	
Notes on installation and use	
Recommended illumination / installation	3
Notes about the use of the rechargeable battery in the Smart Displa	
Safe working order	
Intended use	
Interface doc	0
Instrument Description	7
Delivery package	
Connections	
Rear of the system	
Connectors on the rear	
On/Off key	
Mounting	
Removal from the transport packaging	. 10
Mounting	
Smart Display	
Network	
Procedure for integration into a network:	
Procedure for IP change (if required)	
Prior to start-up	. 17
0	
Operation	
Switching on the peripherals	
Monitor / Mouse	
Smart display	
Switching on the RV Terminal	
Network	
Use of the measuring slide	
Positioning the patient	
Help function	. 19
Maintananaa and Cara	20
Maintenance and Care	
Troubleshooting	
Changing the line fuse	
Changing the battery of the Smart Display	
Cleaning and Care	
Software updates	
Service telephone	
Technical data	23
recimical dala	.23
Manufacturer's Declaration	24



#### Caution

Correct operation of the RV Terminal electronic centration system is vital in order to guarantee optimum instrument safety. Please make yourself familiar with the contents of these instructions prior to start-up of the instrument. Please also observe the user manuals of any additional equipment used. Further information is available from our service department or from authorized representatives.

#### Warning labels and notes

Please pay attention to the safety and general notes contained in the instructions for use and attached to the instrument.



**Caution:** provides information about risks which can lead to damage to property, personal injury or serious physical harm.



This is a **Note** drawing your attention to important information that will simplify your work.

#### Notes on instrument safety

Production and testing are performed in accordance with German and international regulations.
In compliance with Directive 73/23 /EEC, the RV Terminal is a class I instrument.
The system mosts EMC requirements in accordance with DIN EN


- ☐ The system meets EMC requirements in accordance with DIN EN 61326.
- ☐ Please observe all applicable accident prevention regulations.
- □ Carl Zeiss uses a certified quality management system in accordance with DIN EN ISO 9001 and DIN EN ISO 13485.



#### Notes on installation and use



- ☐ Class I laser product according to 21 CFR 1040.10.
- ☐ Protect the instrument from dirt, dust, liquids, extreme temperatures, excessive or direct sunlight.
- ☐ Use the instrument only in closed rooms.
- ☐ Condensed water can form on or in the instrument if it is placed in a location with strongly varying temperatures. To avoid damage, you should leave enough time for the humidity to evaporate before you use the instrument.



I Do not operate the system in explosion-risk areas. Operati	on in	the
presence of inflammable anesthetics and volatile solvents	such	as
alcohol, benzoline or similar chemicals is prohibited.		

Ambient tem	perature f	or the	intended	use: +1	0°C	+40°C.

- ☐ Position the system horizontally. Make sure that the base chosen cannot cause the system to topple.
- ☐ Immediately pull the power plug if you notice any smoke, sparks or unusual noise on the system. Do not use the system until it has been repaired by our service team.
- ☐ Do not place any fluid-filled containers on top of the instrument. Make sure that no fluids can seep into the instrument.

# Notes about the use of the rechargeable battery in the Smart Display

th	e Smart Display
	The battery is only intended for use with the Smart Display.
	Do not disassemble the battery.
	Do not expose the battery to fire or water.
	Avoid any short circuit to the battery contacts, as this can result in fire or damage of the battery.
	If electrolyte liquid has contacted the skin, wash the affected areas thoroughly with soap and water. In the event of contact with the eye flush the eye with water for 15 minutes and consult a doctor.
	Do not recharge the battery in ambient temperatures above +45°C.

☐ When storing the battery, do not expose it to temperatures above +60°C.

#### Safe working order

#### Cleaning / electrical safety

Acetone-containing or aggressive solvents must not be used for the cleaning of the RV Terminal or the measuring slide. Other solvents can affect the function of the RV Terminal and result in the loss of warranty. The system must not be opened for cleaning purposes. Cleaning fluids must not enter the system.
 Do not insert any objects in the ventilation slats or openings of the system, as this can short-circuit the internal components and cause fire or an electric shock.
 The ventilation slats, particularly those on top, must not be covered in order to avoid overheating.
 Disconnect the system from the power supply before changing any fuses.



#### Requirements for operation

	ase ensure that the following requirements are met and that this remains case for further operation of the system:
	All cables and plugs are in perfect condition.
	The power cord has been plugged into a power outlet which is properly earthed.
	The power cord being used is the one designed for use with this instrument.
Ве	fore every use
	Make sure that all specified "Requirements for operation" are fulfilled.
	Do not cover any ventilation openings.

#### After use of the system

Switch the system off via the On/Off key or shut it down via the software if it is not to be used for a prolonged period of time, e.g. overnight.

#### Intended use

The RV Terminal electronic centration system is a high-performance instrument for measuring the centration data of spectacle lenses and for lens and frame consultation.

If the use	er decides	to use	the s	system	for	any	other	purpose	than	that
specified,	he/she ac	cepts fu	ıll res	ponsibi	ility	for th	e con	sequence	es.	

Ш	Please keep	the instructions	for use	easily	accessible	at all	times.
---	-------------	------------------	---------	--------	------------	--------	--------

The RV Terminal is a centration system for determining the optimum positioning of spectacle lenses in front of the patient's eyes during wear, with the fitted frame in position. The operating software and the patient photos are shown on a display and control element. Three system versions can be used for measurement:

- a) system mounted on a table (measurement is made in a sitting position, distance between system front and measuring slide lies between 70 and 150 cm)
- b) system mounted beside a table (measurement is made in a sitting position, distance between system front and measuring slide lies between 70 and 150 cm)
- stand-alone system (measurement is made in a standing position, distance between system front and measuring slide lies between 70 and 150 cm)

RV Terminal is intended for mounting on the floor or the optometrist's consultation table.

De	elivery package
	RV Terminal, specified version
	Measuring slide in storage container
	Standard power cable
	User manual
	Circular level
	Floor markers for stand-alone version only
	Torx and fork wrench – only for table-mounted and stand-alone systems
Op	tional:
	Software for profile photo measurement
	Software for lens and frame consultation (available from spring 2005)
	Smart Display with docking station and pen
	LCD flat-screen monitor
	Logitech cordless mouse, optical USB
	Color printer HP Deskjet 3650c or higher, with USB cable
	Network cable

#### **Connections**




Fig. 1

#### Rear of the system

- 1. Function head
- 2. Connectors
- 3. Power switch, fuse, power connector
- 4. Connecting elements with covers
- 5. Joint
- 6. Inlets and outlets for internal cable routing
- 7. Base
- Metal plate with feet and cable openings



Fig. 2 Connectors

9. Type label

#### Connectors on the rear

From top left to bottom right

#### left

- 1. Power switch
- 2. Fuse
- 3. Power socket with standard power cable

#### right

- Internal USB connector for cordless mouse or – with Smart Display version: WLAN USB pen
- 5. External USB connector for the specified printer
- 6. PS2 connector for the keyboard
- 7. Network connector for connection to PC or network hub
- 8. VGA output for connection with monitor

#### On/Off key

#### Front right

- On/Off key
- 2. Indicator light for operating status



Fig. 3 On/Off key

#### Removal from the transport packaging

Please read the following points carefully and proceed in the order given:

- A Take the system and the peripheral components carefully out of the transport packaging and remove the packaging.
- B For the table-mounted version, position the table horizontally using the circular level contained in the package.

#### **Mounting**



Fig. 4 Opened screws/nuts

- C For the system mounted beside the table and the stand-alone system, position the metal plate horizontally with the aid of the six feet. For this purpose, a fork wrench and a circular level are contained in the packaging.
- D Route the cables to the outside or in a downward direction through the instrument base.
- E Open the screws and nuts as far as possible



F Carefully position the system base on the metal plate, using the pegs / screws and nuts as adjusting aids

Caution: Mind your fingers!

G Connect the metal plate with the base using the screws (a torx wrench is contained in the packaging)




H Guide the cables out of the rear top of the instrument base Caution: Make sure that none of the cables is crushed!

I Combine the function head with the instrument base using the pegs as adjusting aids. It is recommended to seek the assistance of another person here.



Caution: Mind your fingers!





- J Connect the system base with the function head using the screws Caution: Make sure that none of the cables is crushed!
- K Connect the cables to the appropriate connectors (see Fig. 2, Connectors).
- L Cover the connection screws with the caps supplied.
- M Fix the supplied floor markers on the floor with double-sided tape and position them axially in front of the system, at a distance of 80-140 cm, with their arrows pointing to the viewing window (only applicable for stand-alone system).

#### **Smart Display**

#### Functions, status displays and connections

Note: The components important for operation of the RV Terminal are written in **bold print**.

- 1. Status LED: WLAN connection
- 2. Loudspeaker
- 3. Mouse button, right
- 4. Mouse button, left
- 5. Power supply status LED
- 6. Switch: On/Off
- 7. Keyboard: display on/off
- 8. Access to Web browser
- 9. Cursor direction keys
- 10. Microphone




Fig. 5 Font of the Smart Display

- 1. Microphone connector
- 2. Headphone connector
- 3. Power connection for power adapter
- 4. Battery compartment
- 5. Pen in compartment
- 6. Openings for attaching the pen cord
- 7. USB type A connector (two)
- 8. Reset button
- 9. PCMCIA ejection button
- 10. PCMCIA slot
- 11. USB Mini-B
- 12. Mini VGA connector
- 13. Attachment device for safety lock
- 14. Connector for docking station
- 15. Battery lock




Fig. 6 Rear of the Smart Display

#### Pen



Fig. 7 Pen



Fig. 8 Pen with cord

Most functions of the RV Terminal require the pen. The pen also enables you to reset the Smart Display.



**Note:** Store the pen in its compartment when you are not using it. You can also use the cord to prevent the pen from getting lost or misplaced.

#### **Network**

The RV Terminal software is network-compatible; you can directly connect the system to your PC via a crosslinked network cable, or to your network hub via a standard network cable. This enables you to perform several evaluations simultaneously.

It is possible to use monitor / mouse or Smart Display and PCs in the network. The parallel use of Smart display and monitor is not possible.

#### Procedure for integration into a network:


- A Integration into a network requires administrator rights for the evaluation PC (Client) to be connected and the Internet Explorer 5.01 or higher. MS operating systems from Win98 are supported.
- B Connect the RV Terminal to the network hub via a network cable or use a crosslinked network cable for direct connection to a PC.
- C Start the RV Terminal and wait until the green operating status LED lights up on the On/Off switch.
- D Start the Internet Explorer on the evaluation PC to be connected.
- E If your network features DHCP, enter the following text in the address line: <a href="http://RVTerminal10005/miro/default.htm">http://RVTerminal10005/miro/default.htm</a>; instead of "RVTerminal10005", please enter the serial number of your system in the following format: RVTxxxx-xxx-xxxx
- For a home network, please enter the number 192.168.0.72 instead of the serial number. This means that the following URL must be entered: http://192.168.0.72/miro/default.
- G Click on "Install Client"



H Confirm installation of the download by clicking on "Open"



I Confirm installation by clicking on "Next"




- J Wait until any software required has been installed. Depending on the operating system, this can take some time.
- K To start the software (Client) from the RV Terminal in the future, go to "Start" "Programs" "RV Terminal" "RV Terminal Starter".

#### Procedure for IP change (if required)



If you want to change the IP address of the RVT, click on the "Miro IP Configuration" link, which will take you to the following site.



You can change the IP here and set it by pressing the "Submit" button.

#### Prior to start-up

#### Caution

Make absolutely sure to read the "Instrument safety" chapter before you start operating the instrument.



#### Smart display

The Smart Display can be operated with a power supply unit or a rechargeable battery.

A fully charged battery enables operation for up to 4 hours.



Note: We would recommend you to use the Smart Display in the docking station.

#### Charging the battery

Approximately 2 hours are required for recharging when the Smart Display is switched off, and about 4 hours when it is running.

Please charge the battery for at least 5 hours before you use it for the first time, as the battery's service life will otherwise be reduced.





Note: To utilize the full performance of the lithium-ion battery, 3 complete charge/discharge cycles should be run. If possible, charge the battery while the Smart Display is switched off.

#### Meaning of the status LED of the power supply

The status LED is positioned in the upper right corner of the Smart Display and shows the current charge status:

#### In the power unit mode or in connection with the docking station

Off	The Smart Display is switched off.
Green	Battery is charged; power supplied via the power unit.
Green blinking	Battery is being charged; power supplied via the power unit.

#### In the battery mode

Off	The Smart Display is switched off.
Green	Charge level OK
Yellow	Low charge level
Yellow blinking	Charge level critically low

#### Storage

If you do not use the Smart Display in the battery mode every day, connect it directly to the mains via the power unit or the docking station. Remove the battery if you want to store the instrument for a longer period of time Otherwise, there is a risk of the battery running down completely. This can result in damage to the battery and make recharging impossible.



#### Switching on the peripherals

#### **Monitor / Mouse**

As an alternative to the Smart display, you can also directly connect a monitor with VGA connector and a mouse with USB connector and use them as a display / control element. We would recommend using an LCD with a large image angle to allow the patient to actively experience the centration procedure. Recommneded mouse: Cordless Optical mouse from Logitech, with USB connector, Cat. No. 931172-0914 (Logitech).

We are unable to guarantee the functionality of other mouse models.

On system start-up, switch on the monitor first and then the RV Terminal. When the RV Terminal has finished the start-up procedure (green status LED of On/Off switch lights up, application software appears on the monitor), please switch on the mouse. If there is no connection between the mouse and the system, disconnect the USB stick of the mouse from the system for a brief moment.

#### Smart display

When starting the system, first start up the RV Terminal completely (green status LED of On/Off switch lights up) before you start the Smart Display. Then click on the "Connect to RVT" button on the Smart Display to connect the Smart Display with the RV Terminal.

#### Switching on the RV Terminal

Connect the RV Terminal to the mains via the power switch on the rear of the unit above the mains connector. Then switch on the RV Terminal by pressing the On/Off switch. The program is then loaded automatically. This takes about 2.5 minutes. As soon as the starting procedure is finished, the starting image is displayed on the monitor and the green LED below the power switch lights up.



Note: To ensure rapid availability, we recommend switching the RV Terminal on/off only once a day.

#### Network

After the start of the RVT, the software can be started on the customer PC via "Start" - "Programs" - "RV Terminal" - "RV Terminal Starter", as described above. If the RVT cannot be reached because it is not switched on, a message will be displayed.

Fig. 9 Open the measuring slide

#### Use of the measuring slide

Fit the selected frame in its final form on the patient's face. The ear and nose fit and the horizontal orientation in particular must no longer be changed when the frames are glazed in the lab.

Take the blue levers of the measuring slide between your right thumb and index finger and open the slide.

Insert the frame into the top mounting grooves with your left hand. Close the measuring slide by slowly releasing the pressure of your right thumb and index finger. The frame engages in the lower mounting grooves.



Use the small indentation under the nose to check the center position of the measuring slide on the frame.

Fig. 10 Close measuring slide

#### Positioning the patient

- a) system mounted on and beside the table: measurement is made in seated position
- b) Stand-alone system: measurement is made in standing position
- ☐ Demonstrate to the patient how to adopt a relaxed position in front of the system. Ensure that the patient's head and body are in a natural posture.
- ☐ For an optimum profile photo, ask the patient to turn his/her body 90° to the right or left.
- ☐ To make this easier for the patient, we would recommend that you attach a fixation aid at average eye level.

#### **Help function**

☐ If you move the mouse / pen to the right edge of the software interface, a window appears from the right providing information and notes about the current interface, e.g. on operation.



#### Warnings

- ☐ The system must be opened by trained service staff only. Never open the RV Terminal, as this can result in the immediate loss of warranty. Carl Zeiss will not be liable for any damage caused by opening the system.
- ☐ The RV Terminal must never be connected to the mains when it is opened or defective.

#### **Troubleshooting**

There may be various reasons for malfunctions.

Please check whether

- □ the RV Terminal has been connected to the mains supply;
- ☐ the fuses of your mains supply are working properly;
- ☐ the power fuses of the RV Terminal work properly.
- Only for network connection: the network connections must be OK, and the hub or server must be switched on.
- Only for Smart Display: network connection to RV Terminal exists

#### Meaning of the status LEDs for the network connection

The LED is positioned in the upper left corner of the Smart Display and shows the quality of the network connection:

Off	No signal, no connection	
Green	Good signal quality	
Yellow blinking	Poor signal quality	

#### Changing the line fuse

Above the power cable connection you will find a fuse compartment with two fuses (T3, 15A L 250 V 5x20 IEC127-2/3). To change them, proceed as follows:

- A Switch off the RV Terminal and remove the power cable.
- B Pull out the fuse holder with a screwdriver.



- C Replace the defective fuses in the fuse holder. **Caution:** Only use spare fuses of the same type.
- D Press the fuse holder fully into the unit.
- E Connect the power cable and switch RV Terminal on again.

# Changing the battery of the Smart Display



Your Smart display contains a lithium-ion battery.

**Caution:** Replace the battery only with a battery of the same type (airpanel V110 series battery)

- 1. Open the lock of the battery compartment.
- 2. Remove the old battery.
- 3. Insert the new battery.
- 4. Lock the battery compartment to prevent the battery from accidentally falling out.

Do not dispose of the old battery as normal waste. In most countries, the address of the nearest collecting point for used batteries is available from your local waste disposal company.



Fig. 11 Changing the battery

#### **Cleaning and Care**

### M

#### Caution

If you want to clean the instrument, switch off RV Terminal and the Smart Display and pull out the power plug.

- ☐ You can clean the glass front of RV Terminal with a soft, moist cloth. If required, use a standard glass-cleaning agent.
- ☐ Clean the Smart Display using a dry or slightly moist microfiber cloth.

  Never use any cleaning agents that contain ammonia or alcohol, since these can damage the Smart display and the housing.

#### Software updates

Software updates can be installed via a USB Memory Stick.

- A Insert the USB Memory Stick in the instrument
- B Switch on RV Terminal.
- C The software update is recognized automatically and installed
- D On conclusion of the installation, a message appears on the test field, and the instrument is restarted automatically after 10 seconds.
- E During this time, remove the USB Memory Stick.
- F Only for Smart Display: To implement the changes also on the control unit, the Smart Display must be reset. To do this, press the reset knob with the tip of the pen.




Fig. 12 Reset knob of the Smart Display

#### Service telephone

Should you have any technical problems with your RV Terminal, you can get help from your local sales agency via the service telephone.

Telephone: ++XXX or ++XXX

Telefax: ++XXX Email: XXX

#### Warranty

The warranty period for the installed components is 1 year.

Mains voltage 90-240 V AC ± 10 %, 50 ... 60 Hz

Power 160 VA

Ambient conditions for the

intended use

Temperature: +10 °C ... +40 °C

Humidity: 30 %...90 %

(no condensation)

Transport and storage

conditions

(in original packaging)

Temperature:

-25 °C ... +60 °C

Humidity: 10 % ... 100 %

(no condensation)

Loudspeaker connection

(Smart Display)

3.5 mm stereo connector

Dimensions (height x width x

depth)

System mounted on table: 51.7 x 24.0 x 28.0 cm

System mounted beside table: incl. metal plate

124.7 x 60 x 50 cm

Stand-alone system: incl. metal plate

149.5 x 60 x 50 cm

Weight of system on table: 16.0 kg

beside table: 31.8 kg stand-alone: 36.5 kg

Power fuses T3,15A L 250V 5x20 IEC127-2/3

Subject to change in the course of further development.

#### **Standards and Regulations**

The RV Terminal meets the requirements of the following standards and regulations:

Standard	Year	Contents
DIN EN 60601-1-1	08/200	Medical Electrical Equipment -
	2	Part 1-1: General Requirements for Safety.;
		Collateral Standard: Regulations for the
		Safety of Medical Electrical Equipment
DIN EN ISO 14971	03/200	Application of risk management to medical
	1	devices
Laser Class I in acc.	Octobe	
with DIN EN60825	r 2003	

#### Low voltage directive

The RV Terminal meets the requirements of EC low voltage directive 73/72/EEC and its German equivalent, 1. GSGV - 1. Verordnung zum Gerätesicherheitsgesetz.



Hier kommt die Konformitätserklärung von A-QS/Frau Pflanz hinein Hier kommt noch die declaration of conformity für Relaxed Vision von A-Q/Frau Pflanz hinein.



# ZERTIFIKAT

Die

#### **DQS** Deutsche Gesellschaft zur Zertifizierung von Managementsystemen mbH

bescheinigt hiermit, dass das Unternehmen

#### **Carl Zeiss**

Geschäftsbereich Augenoptik Werk Aalen D-73430 Aalen

für den Geltungsbereich

Entwicklung, Herstellung und Vertrieb von Brillengläsern, vergrößernden Sehhilfen, Schutzbrillen und augenoptischen Geräten

ein

#### Qualitätsmanagementsystem

eingeführt hat und anwendet.

Durch ein Audit, dokumentiert in einem Bericht, wurde der Nachweis erbracht, dass dieses Qualitätsmanagementsystem die Forderungen der folgenden Norm erfüllt:

#### **DIN EN ISO 9001: 2000**

Ausgabe Dezember 2000

Dieses Zertifikat ist gültig bis 2005-03-19

Zertifikat-Registrier-Nr.: 231632 QM

Auszug aus Zertifikat-Registrier-Nr. 015724 QM

Frankfurt am Main, Berlin 2002-03-20

GESCHÄFTSFÜHRER

Geschäftsstellen: D-60433 Frankfurt am Main, August-Schanz-Straße 21 D-10787 Berlin, Burggrafenstraße 6







## CERTIFICATE

# DQS Deutsche Gesellschaft zur Zertifizierung von Managementsystemen mbH

hereby certifies that the company

#### **Carl Zeiss**

Ophthalmic Products Division Plant Aalen D-73430 Aalen

for the scope

Designing, Manufacturing and Distribution of Spectacle Lenses, Low Vision Aids, Protective Eyewear and Ophthalmic Instruments

has implemented and maintains a

#### **Quality Management System.**

An audit, documented in a report, has verified that this quality management system fulfills the requirements of the following standard:

#### **DIN EN ISO 9001: 2000**

December 2000 edition

This certificate is valid until

2005-03-19

Certificate Registration No.:

231632 QM

Excerpt from Certificate Registration No.

015724 QM

Frankfurt am Main, Berlin

2002-03-20

Dr.-Ing. K. Petrick

Dipl.-Ing. S. Heinloth





MANAGING DIRECTORS

D-10787 Berlin, Burggrafenstraße 6



#### Carl Zeiss AG

Geschäftsbereich Augenoptik D – 73428 Aalen Germany www.zeiss.de/opto optics@zeiss.de